Calculation for Tree Box Storage Capacity Project Name: MSD Reviewer:____ Date Submitted: WM No.____ Property Address:_____ Development/Property Name:_____ GMP Number:_____ Design Firm:____ Design Engineer:_____Telephone:_____Email:____ KY PE No.:_____ Step A. Site Planning Recommendation Define goals and primary function of Tree Boxes based on the Tree Box Step by Step Design Procedures beginning on page 18.5.13-5 as well as Table 18.5.13-A. Refer to these sections as needed throughout the remainder of this calculation sheet. Step B. Determine the Required Water Quality Volume Rain Event, RE_{WOV} in inches (Refer to Chapter 18.3; A minimum depth of 0.6 inches must be used): inches Step C. Calculate the Required Water Quality Volume (WQ_V Required) of water to be removed by Tree Boxes 1. A = Contributing drainage area to tree boxes: ft^2 2. RE_{WOV} = Required WQ_V Rain Event in inches: inches 3. I = Impervious cover of the contribution drainage area in percent: $R_V = 0.05 + 0.009 \text{ (I)} =$ 4. WQ_V Required = $(A/12)(RE_{WOV})(R_V)$ = ft^3 Step D. Determine minimum surface area of Tree Box 1. Refer to table 18.5.13-A 2. WQ_V=required water quality volume: ft^3 3. h=average height of water above the treebox bed during WQ_V rain event ft 4. d=depth of tree box 5. P=porosity of the soil mix in the tree box (% void): 6. A=Surface area of the ponding area of the tree box= $(WQ_v)/[(d)(P)+h]$ ft^2 Step E. Calculate the Provided Water Quality Volume (WQ_V Provided), or storage capacity of Tree Boxes 1. A = Area of tree box:2. φ = porosity of media (% void): $\frac{0}{0}$

Step F. Compare the minimum calculated surface area of the tree boxes to the input area of tree boxes

3. M = depth of media

4. P = ponding depth of water
5. WQ_V Provided = (A)[φ(M) + P]

Calculation for Tree Box Storage Capacity 1. Is the area in step E.1 greater than the minimum surface area calculated in step D.6?

1.	. Is the area in step E.1 greater than the minimum surface area calculated in step D.or	
Step G.	Determine the Managed Water Quality Volume (MWQ _V)	
1.	Determine the GMP Management Capacity of the tree box in percent (Refer to Table 18.3-C for percent). Please attach model printouts or other documentation to verify retention times as required by Table 18.3-C.	%
2.	. $MWQ_V = (1/100)(GMP \text{ Management Capacity in percent})(WQ_V \text{ Provided}) =$	ft^3
3.	. Is all of the WQ_V Required managed or treated (i.e. is MWQ_V greater than or equal to WQ_V Required)?	
	If No, adjust WQ _V Provided parameters to allow for greater storage capacity and/or proceed to Step H.	
	If Yes, proceed to step J.	
Step H.	. Calculate the Required Remaining Water Quality Volume (RWQ _V)	
1.	. Required RWQ _V = $2(WQ_V \text{ Required - } MWQ_V) =$	ft ³
Step I.	Select Alternate GMPs to Treat RWQ _V . Examples may include:	
	Check all that apply. Include additional calculation sheets as necessary	
	□ Green Wet Basin	
	□ Green Dry Basin	
	□ Catch Basin Inserts	
	□ Proprietary Water Quality Units	
	□ Other	
1.	. How much additional WQ_V is removed by the Alternate GMPs?	ft^3
2.	. Does the Alternate GMP remove all the Required RWQV?	
3.	. If Yes, proceed to step J.	
	If No, alter existing GMPs or add new ones to provide adequate storage.	
Step J.	Complete O&M documentation.	
Additio	nal Calculations and Explanation (Required if design deviates from calculation sheet):	